## **Short Ratchet Strap**





Code	Strap Width	Length	BL/Kg
05346	25	1800	680

## Notes about load limits where shown

SWL or WLL = Safe working load limit (kg): This is the maximum weight the product should carry.

BL = Break load: This is the maximum weight to break for the product and will vary from batch to batch. You should only use the product at the WLL or 1/4 the break load.

The above are guides for sizing of products and not a recommendation.

Do not use any product for lifting unless drawing is marked suitable for lifting - with this symbol



NB. This drawing and its dimensions to be used as a guide. For dimension critical applications please ask

STEELGEAR.CO.UK
UNIT 9 THESIGER CLOSE
WORTHING
BN11 2RN

www.steelgear.co.uk
info@steelgear.co.uk
Steelgear is a trading name of DARAC LTD

Title:

Short Ratchet Strap

Dimensions in mm

SIZE
PART NO.

See CODE in above table
REV